

# MSA Gas Detection System

## TRIGARD® Monitoring System for Oxygen, Toxics and Combustible Gases



- ➔ Adjustable range
- ➔ Multiple sensor mounting options
- ➔ AC- or DC-powered
- ➔ On-board relays
- ➔ NEMA 4X design
- ➔ LCD display with highly visible LED indicators
- ➔ Piezo horn with horn silence button
- ➔ Long-life, MSA-designed sensors
- ➔ Simple push-button calibration
- ➔ Available as single-point or 3-point unit

### Application

The MSA TRIGARD Monitoring System is designed for monitoring chlorine, sulfur dioxide and other toxic gases, combustible gases, as well as for oxygen deficiency or enrichment. These new monitors were designed specifically for water and wastewater facilities which are typically large producers of these gases. The MSA TRIGARD Monitor offers an affordable monitoring solution for a variety of needs.

### Advanced Features

- **Sensor Disconnect Under Power**  
MSA's patented feature allows for sensor change-out without declassifying a hazardous area.
- **Interchangeable Smart Sensors**  
Pre-calibrated sensor modules are ready for installation out of the box. Sensors can be replaced in the field without the use of tools. The unit quickly recognizes the new sensor type and reconfigures alarm and relay settings to optimize the new sensor.
- **State-of-the-Art Display**  
Liquid crystal display conveniently alternates between sensor reading and gas type and features scrolling messaging, indicating ongoing diagnostic checks such as sensor "end-of-life" condition.

**World-Class Design**

Engineering efforts feature a single-board design for ultimate reliability and serviceability. The mounting enclosure has been designed to be separate from the electronics and sensor, allowing for problem-free installation and servicing.

**Onboard LEDs and Relays**

"Quick-check" LEDs and four relay outputs allow for increased indication of alarm and fault conditions. "Quick-check" LEDs, viewable from up to 50 feet, indicate NORMAL (green) and ALERT (red) status conditions. Field-programmable alarm levels and normally energized/de-energized, normally opened/closed and latching/non-latching relay functions offer three levels of alarm and a fault.

**Options**

- One or two strobes
- Back-up battery
- Internal power supply

**Sensor Options**

- Oxygen, toxic and combustibile sensors
- Integral mounting
- Remote General Purpose
- Remote Explosion Proof
- Pre-wired shielded cable for sensors in 25, 50 and 100 foot lengths (oxygen & toxic)



Factory-assembled remote sensors are available in 25-, 50- and 100-foot lengths.

TRIGARD Gas Monitor showing single local sensor with two remote sensors attached.



**Specifications**

<b>Gas Type</b>	Toxics, oxygen and combustibile
<b>Gas Sampling</b>	Diffusion
<b>Output Type</b>	4-20mA, 3-wire (non-loop power) (single-point only) ModBus RTU (3-points)
<b>Sensor Location</b>	Local or remote sensor (up to 100 ft.)
<b>Enclosure</b>	General-purpose plastic enclosure
<b>Sensor Temperature Range</b>	14°F to 104°F
<b>Accuracy</b>	Repeatability +1% FS
<b>Sensor Life</b>	18 months to 2 years
<b>Relays</b>	LEDs and relays – 5 Amp SPDT @220 VAC or 30 VDC
<b>Power Input</b>	Internal 120VAC/24VDC power supply
<b>Alarm Type</b>	Peizo horn (75 dB) with horn silence button
<b>Battery Backup</b>	Optional (up to 24 hours)
<b>Environmental Protection</b>	Designed to meet NEMA 4X

Note: This Bulletin contains only a general description of the products shown. While uses and performance capabilities are described, under no circumstances shall the products be used by untrained or unqualified individuals and not until the product instructions including any warnings or cautions provided have been thoroughly read and understood. Only they contain the complete and detailed information concerning proper use and care of these products.



ID 07-2109-MC / Apr 2009  
© MSA 2009 Printed in U.S.A.

**Corporate Headquarters**  
P.O. Box 426, Pittsburgh, PA 15230 USA  
Phone 412-967-3000  
www.MSAnet.com

**U.S. Customer Service Center**  
Phone 1-800-MSA-2222  
Fax 1-800-967-0398

**MSA Canada**  
Phone 1-800-672-2222  
Fax 1-800-967-0398

**MSA Mexico**  
Phone 01 800 672 7222  
Fax 52 - 44 2227 3943

**MSA International**  
Phone 412-967-3354  
Fax 412-967-3451

**Offices and representatives worldwide**  
For further information:

